

G5 MENU TREE

To open the menu, press 1-2-3-4 and press MODE twice.
If <User Mode ID, = 1> appears, press the MODE button.
<SYSTEM MENU> should be displayed; press the ENTER button.

- **Drive Thru Volumes**
 - Inbound Mic Volume
 - Outbound Talk Volume
 - Vehicle Alert Volume
 - Outbound Greeter Message Volume
 - External Audio Input Volume
 - Mic Preamp Gain

- **Monitor Volume**
 - Inbound Listen
 - Outbound Talk
 - Vehicle Present
 - Vehicle Approach
 - Page Messages
 - External Audio In
 - Greeter Messages

- **Night Volume**
 - Day Outbound Talk Volume Setting
 - Reduce Drive Thru Volume At Night By

- **Registration**
 - Add A Headset
 - Remove Headsets
 - List All Headsets

- **Noise Reduction**
 - Inbound Mic Noise Reduction Level
 - Acoustic Echo Canceller

- **Set Time & Date**
 - Time
 - Date
 - Time zone

- **Global Settings**
 - Audio And Text Prompts Language
 - Drive Thru Audio Duplex Mode

- Page Channel Heard By Order Taker
- Number Of Base Stations At This Site
- "Store Is Now Closed" Prompt
- Order Point Prompts In English
- Order Point Prompts In Spanish
- Order Point Prompts In French
- Order Point Prompts In German
- Order Takers In Cross Lane Mode
- Page Messages Can Cross Lanes
- Order Point Talk With No Vehicle
- Vehicle Detector 1 Type
- Vehicle Detector 1 Minimum
- Auto Un-Mute HS Mic In HFree Mode
- External Audio Routing Mode
- External Audio In Gate Threshold Level
- Mute External Audio In When Busy
- Haptic Alerts On HS
- Blue LED Alerts On HS
- **Headset Setup**
- **O.T. Modes Setup**
 - Manual Listen/Push To Talk
 - Manual Listen/Manual Latching Talk
 - Auto Listen/Push To Talk
 - Auto Listen/Manual Latching Talk
 - Hands Free
 - Outside
 - Always On
- **Site Scheduling**
 - Regular Site Schedule
 - Holiday/Exception Schedule
- **Site Information**
- **Digital IO Setup**
- **Change Passcodes**
 - Change User Passcodes
 - Change Installer Passcodes
- **Installer Setup**
 - Load Installation Settings
 - Save Installation Settings
 - Use Custom Tech Service Message
 - Create Custom Tech Service Message
 - Number Of Lanes At This Site
- **Factory Setup**
 - Restore All Factory Settings
- **Network Setup**
 - MAC Address
 - Web Server Enabled

- Electronic Mail Enabled
- IP Address
- Subnet Mask
- Default Gateway
- Email Server Address
- Your Email Address Suffix
- Web Server Port Number
- Email Port Number
- **Reboot System**
- **Revision Levels**